

FLEX-SHIELD

POLYCARBONATE CLEANING & CARE GUIDELINES

Important Cleaning & Care Instructions:



Easily clean surface using neutral soap & water or other Plastic Safe Cleaners.

Use a microfiber or soft cloth and rinse well with clean water.

* Avoid Dry Cleaning, as sand and dust particles clinging to the exterior of the panel may cause scratches to the surface.

* Never use squeegees, sharp object or razors on surface area.



Avoid any aggressive cleaning agents, such as commercial alcohol or ammonia-based disinfectants, as these may cause crazing or damage.

* Always Test Cleaners & Disinfectants in a small inconspicuous area prior to cleaning entire panel to insure against adverse results.

* Do NOT leave cleaners on polycarbonate surfaces for extended periods of time.



Store product inside to avoid extended exposure to direct sunlight or moisture.

Avoid temperatures over 140°F / 60°C

Should you desire to use a cleaning agent not on the approved list, or wish to use the product in a questionable location, please consult a CompuCaddy Representative.

Use only compatible Polycarbonate Cleaners.

Compatible Chemical Cleaners:

Methyl Alcohol

Isopropyl Alcohol

Petroleum Ether (BP 65°)

Ethyl Alcohol

Heptane

VM&P Naphtha

Butyl Alcohol

Hexane

Compatible Biodegradable Cleaners:

Brilliance - Plastic Cleaner

Klear to Sea

Use only compatible Polycarbonate Disinfectants.

Compatible polycarbonate disinfectants include:

sBioMed Steriplex SD

Safetec Surface Wipes

Contec Healthcare Perodox RTU

Contact Healthcare PS-911 EB Prostat Sterile Wipes.

CompuCaddy, LLC

Customer Service

Phone: 502-561-0732

Fax: 502-561-0734

E-Mail: sales@compucaddy.com

Technical Support

Phone: 502-561-0732 Ext.114

E-Mail: techsupport@compucaddy.com